


Inkema

Loading bays • Dock shelters • High-speed doors
Fire doors • Free standing frames and dock houses • Scissor tables
Folding bridges • Industrial doors



Instructions manual Hydraulic dock leveller Models: **RH65**

MOBILE YARD RAMP



Contents

01 – Introduction.....	3
02 – CE Declaration	4
03 – Instructions for use	5
03.01 – Before use	5
03.02 – During use	5
03.03 – After use	6
03.04 – Precautions for use.....	6
04 – Maintenance.....	7
04.01 – Hydraulic oil	7
04.02 – Maintenance plan.....	8
05 – Electrical connection	8
06 – Conditions and terms of use.....	8
07 – Contact	9

01 – Introduction

This manual is a guide for the correct and safe use and maintenance of the **RH65** ramp.

Complying with the contents of the instruction manual ensures a long useful-life of the machine and respecting the safety standards prevents the most common types of accidents that could occur during work or maintenance.

The instructions included in this manual do not guarantee work safety and do not exempt the operator from following any safety standards, laws, rules or local and national regulations.

The service standards presented in this manual are valid exclusively for mobile levelers when loading and unloading trucks.

In the event of losing this instruction and maintenance manual, a copy must be requested specifically for this machine. This manual must always be kept with the machine for consultation purposes at any given moment or if any doubt arises regarding the use of the machine.

The manufacturer is not responsible for the machine's operation, placement or maintenance. The operator is responsible for good safety and maintenance practices.

The operator is responsible for reading and understanding this manual prior to using the machine.

Cautiousness and an adequately trained use not only protects the operator from accidents but also the personnel who depend on its work.

The information included in this manual is valid from the moment of its publication.

All photographs and drawings are generic and therefore may vary due to the continued research and development carried out by **INKEMA**

Consult the Technical Department if any discrepancy arises.

This manual is an integral part of the machine and must be attached to it when sold.

02 – CE Declaration



DECLARATION OF CONFORMITY

INKEMA SISTEMAS, S.L. declares, under its own responsibility, that the electro hydraulic dock levellers:

Make : **INKEMA**
Model : **RH65** with a capacity of **6000 Kg^(*)**
Year of manufacture : **2013**

Are compliant with the essential requirements of the following directives:

2006 / 42 / EC	Machine safety.
2004 / 108 / EC	Electromagnetic compatibility.
2006 / 95 / EC	Low voltage.

And have been calculated and designed pursuant to the following European standards:

EN 1398:1998	Dock levellers
EN 292-2:1991	Machine safety. Basic concepts. General design principles.
EN 61000-6-2:2001	Electromagnetic compatibility. Basic immunity concepts for industrial environments.
EN 61000-6-4:2001	Electromagnetic compatibility. Basic emissions concepts in industrial environments.
EN 60204-1:1997	Machine safety – Electrical equipment – General provisions.

() In the event that the capacity is other than 6000kg, the respective EC certificate will be attached to this manual.*

03 – Instructions for use

03.01 – Before use

Visually check that the leveler is in perfect working condition.

To raise the leveler to the load surface level, connect the handling circuit by turning the Red button. The green LED will light up.

To raise the leveler, press and maintain the elevation button.

The handling circuit is disconnected by turning the Red button. The green LED will switch off.

Center the vehicle against the leveler.

Make sure that the vehicle is perfectly immobilized and blocked (stop the engine, set the emergency brake and block the wheels).

Connect the handling circuit by turning the Red button. The green LED will light up. Press the elevation button again for an instant to unblock the leveler and start the descent. The leveler will lower by means of its own weight at a controlled speed.

Allow the leveler to lower gradually and support it using the truck's load surface.



Check that the entire width of the lip is firmly supported on the vehicle's load surface. The load surface must be NO WIDER than 130 mm.

Attach the leveler chains to the truck so the leveler cannot move.

03.02 – During use

The leveler will be completely supported on the load surface of the truck. The hydraulic cylinders shall **NOT** be kept blocked so the leveler can adapt to the height of the load surface, which will vary in accordance with the truck's suspension variation.

Make sure that the emergency stop is **NOT** activated and that the leveler is connected to the power supply.

VERY IMPORTANT:

Carrying out loading or unloading operations are strictly forbidden while the emergency stop is activated or while the leveler is not being supplied by any power.

Never overload the maximum nominal load (see characteristics plaque).

Make sure that the leveler does not lose its support on the load surface during load transport. If it loses its support, immediately activate the emergency stop.

Trucks must move with caution. The maximum transport speed calculated for the leveler is 10 km/hour.

03.03 – After use

Remove the chains attached to the truck.

Raise the leveler and close the lip prior to the truck leaving its loading position. This is achieved by pushing the elevation button and raising the leveler enough to clear the truck.

Block the leveler in this position by turning the selector to the OFF position. From this moment, the truck can be removed.

Once the truck has been removed, turn the selector to the ON position and press the elevation button to unblock the leveler and lower it to its lowest position.

03.04 – Precautions for use.

Make sure that the emergency stop is not activated.

Never overload the maximum nominal load (see characteristics plaque).

Prior to each maneuver, verify that there are no personnel in the work area.

Make sure that the leveler is properly supported on the truck's load surface while coupling the entire lip on an approximated width of 130 mm.

The function of the hydraulic group is to perform the necessary movements in order to handle the dock leveler only. **It should never be used to support and/or raise loads.**

Prior to raising the leveler, make sure that other equipment does not obstruct it (doors, etc.)

04 – Maintenance

The leveler's proper operation and long useful-life depend mostly on the preventive performed maintenance.

Advanced maintenance must only be carried out by **INKEMA** Technical Support or authorized personnel.

This type of maintenance is made with the aim of ensuring the product's safety and use from the moment it is installed.

Any modification, repair or handling of the product that does not comply with these guidelines will cancel the one-year warranty period as well as **INKEMA** responsibility with regard to the product.

Continued greasing, painting and monitoring are the best guarantee to ensure a long and good performance.

04.01 – Hydraulic oil

The hydraulic oil must be changed once every two years.

The oil must contain antifoaming, rust preventive and water absorption agents. If winter temperatures are very low, low-density oil must be used with a stable viscosity index at low temperatures.

Different oils must not be mixed as new oil may have a different oxidation resistance, thus affecting the duration of the original oil.

Checking the oil level every 6 months is important. The oil tank must be filled until it almost overflows the closing cap at its lowest position.

The machine comes equipped with **HVI-32** oil.

The hydraulic oil for dock levelers that are in refrigerated warehouses must have the specific properties for use with the temperature to which it is exposed. If this is the case, please inform the manufacturer must be informed of the conditions in which the machine will work so it can be equipped with special oil.

04.02 – Maintenance plan

Scheduled maintenance	Daily	Monthly	Every 6 months	Every Year	Every 2 Years
General state of the machine	◆	◆	◆	◆	◆
Greasing			◆	◆	◆
Hydraulic oil level			◆	◆	◆
Oil leak inspection			◆	◆	◆
Weld inspection				◆	◆
Rod inspection				◆	◆
Lateral adhesive strip inspection				◆	◆
Painting inspection				◆	◆
Flexible fittings				◆	◆
Handling velocity				◆	◆
Check parachute valve					◆
Hydraulic oil change					◆

05 – Electrical connection

The specific electrical diagram for each machine model is inside the control panel and is supplied with the leveler.

06 – Conditions and terms of use

- Nominal load rating: 6t (or specific to supplied model, see identification plate).
- Electric motor voltage 230/400 volt, 3F 50Hz.
- Electric motor power 0.75 Kw.
- Output voltage to 24V emergency electrovalves, AC.
- Max. working pressure of the hydraulic circuit 140 kg/cm² (Bar).
- Working temperature range (-10°C +40°C).
- Noise level <70db.
- Max. transport speed 10Km/h.
- Max. work inclination 12.5% (7°).
- Do not operate the machine while the emergency stop is activated or the power supply has been disconnected.

07 – Contact



Inkema Sistemas S.L

C/ Galileo, 2 – Naves 7 y 8
Apartado de correos 132
08150 Parets del Vallés
Barcelona – (Spain)

Branches in Spain:

Tel: +34 93 544 47 08
Fax: +34 93 572 30 11
inkema@inkema.com
serviciotecnico@inkema.com

GPS: N 41° 33' 30" – E 02° 14' 42"

International distribution:

Tel: +34 93 544 47 08
export@inkema.com

Production centre in Rumania:

Str. Via Brescia esqu. ViaSperanza –307221
Chisoda – Timis – (Romania)
Tel: 0040 256 215 819
Fax: 0040 256 215 818